


POWER CONTROL UNIT

■ DISCRIPTION

- The power control unit is installed in the motor compartment. The power control unit stores high-voltage parts, wiring, and control parts in a compact manner.
- The unit box stores the parts listed below
 - Motor Inverter
 - EV ECU
 - Battery ECU
 - On-Board Battery Charger
 - HWS (Heated Windshield System) Controller & Electrical Leakage Detector
 - Cooling Fan
 - Power Steering ECU
 - Air Conditioning Inverter



Power Control Unit